

Iron on Sleeve Badges

1. Empty your Iron - Use no steam.
2. Heat your iron to the cotton setting.
- 3 Use a piece of baking paper and place it over the top of your label.
4. Iron and press FIRMLY down, ideally not moving your iron, press hard over the top of your label for about 7 - 10 seconds. The 7 - 10 seconds of heat will be enough to melt the glue and activate it. You don't need longer. About 10 seconds will do it.
5. You can then run your iron back and forth over the label and baking paper for another 5 seconds, moving it around this time.
6. Then - leave your label to cool down and set.
7. After about a minute cooling down, your label will be set enough to touch.
8. The glue in our labels will continue to set hard over the next 24 hours.
9. Do not wash your garment for the next 24 hours.